de Heus- XCMG
Stougjesdijk 153 3271 KB
Mijnsheerenland NL
info@heustractors.com
+31 (0) 186 61 2333

XCMG XE27E PRO

Fitted as standard with

- Kubota Stage V engine (D1305 - 18.2 kW)
- Hydraulic system with variable pump
- Proportionally controlled demolition/sorting function (2 auxiliary hydraulics)
- Adjustable auxiliary hydraulics (pressure & flow)
- Air conditioning (heating & cooling)
- Heated cabin with ROPS / TOPS certification
- Rubber tracks (300 mm)
- Dozer blade with float function
- Quick coupler connection suitable for attachments such as tilt bucket, thumb or grapple
- 7" LCD control display
- Strong hydraulic performance (82.8 L/min main pump, 24.3 MPa system pressure)
- Compact swing beam with stable undercarriage
- Safety cabin according to ISO 3471 / 12117 / 10262

€34,620.00

Specifications

DIMENSIONS

8 ft digging depth with flat floor	2312
Boom length	2090
Chassis width	1500
Counterweight free space	528
Cradle base	1560
Ground clearance	290
Height of dozer blade	300 mm
Height of tracks	452
Height to top of roof	2620
Max cutting depth of dozer blade	330
Max. Digging depth	2800
Max. Digging height	4390
Max. Tipping height	3210
Max. Vertical digging depth	2310
Max. excavation radius	4750
Maximum lifting height of dozer blade	310
Maximum reach at GRP	4640
Min. forcing radius	1980
Minimum unloading height	955
Overall length with bin	4225
Overall width	1500
Tail swing radius	790
Track length	1560
Track width	1200
Width of tracks	300
Width of upper structure	1350

ENGINE

Cooling	Water
Power in kW	18.2

HYDRAULIC SYSTEM	
Driving system pressure	243
Main pressure safety valve	243
Main pump output	2400
Steering pressure	35
Swing system pressure	210
Type of main pump	1 variable pump

OTHER	
Diesel tank	38
Hydro tank	22

TECHNICAL SPECIFICATIONS	
Arm digging force	14
Gradeabillity	58
Ground pressure	26.4
Max traction force	29.7
Max. Digging force	23
Rotation speed	10

WEIGHT	
Own weight	2780

Pictures

XCMG
XE27E PRO

XCMG
XE27E

XCMG
XE27E

XE27E

XCMG

CAUTION
Prior starting engine:
- ensure no people in the danger zone;
- sound horn;
If the engine can't be started up within 15 seconds:
- turn the key to the position "OFF";
- wait for 2 minutes;
- start the engine.

CAUTION
Lift Capacity Chart